


TDi Threshold Installation Detail



For all 65 and 100TDi Threshold Drainage systems



- * The entire door track and TDi are set in above and separate to waterproofing. Therefore waterproofing must be completed first.
- * Install the door track sub sill.
- * When installing the TDi, the tray needs to be slightly deeper than the lowest part of the Sub sill.
- * Standard installation sequence generally has the door track sub sill in place before the drain. Therefore the tray may need to be slightly deeper than lowest part of the sub sill to allow the drain channel to slide underneath the sub sill.
- * Refer to:
AS1428 Design for Access and Mobility
AS4654 for Waterproofing

