


# 65Tii40 TIMBER FLOOR/DECK



When 65Tii40 is running parallel to joist/bearer



When 65Tii40 is running perpendicular to joist/bearer

